



Applies To: **See VEHICLES AFFECTED**

January 28, 2003

MIL Comes On With DTC P1457: EVAP Bypass Solenoid Valve Failure

SYMPTOM

The MIL is on, and DTC P1457 [leak detected in EVAP control system (EVAP control canister system)] is set.

PROBABLE CAUSE

The EVAP bypass solenoid valve can fail due to corrosion. The solenoid valve may get water inside. If the water contains road salt, the solenoid windings could corrode, causing the valve to fail. In a few rare instances, the corrosion could be severe enough to cause an internal short in the solenoid valve, which could damage the ECM/PCM. If this happens, both the bypass solenoid valve *and* the ECM/PCM would need to be replaced.

Vehicles driven in the Northeastern part of the U.S. are more likely to have this problem because of the salting of roads during the winter months. Vehicles driven where salt is not used on the roads are much less likely to have this problem.

VEHICLES AFFECTED

1998–02 Accord
 1998–00 Civic
 1998–01 CR-V
 2000–02 Insight
 1999–03 Odyssey
 2003 Pilot
 2000–03 S2000

CORRECTIVE ACTION

Test and, if necessary, replace the EVAP bypass solenoid valve. Replace the ECM/PCM if needed.

PARTS INFORMATION

Refer to the parts catalog for the appropriate part number and Honda code.

WARRANTY CLAIM INFORMATION

In warranty: The normal warranty applies.

OP#	Description	FRT
123505	Retrieve the DTC. Store the immobilizer system key codes. <i>Write the DTC in the ECU field of the warranty claim form.</i>	0.6
124100	Replace the EVAP bypass solenoid valve.	0.4
121100	Replace the ECM/PCM.	
	1998–02 Accord	0.4
	1998–00 Civic	0.3
	1998–01 CR-V	0.3
	2000–02 Insight	0.3
	1999–03 Odyssey	0.4
	2003 Pilot	0.4
	2000–03 S2000	0.3

Failed Part: EVAP Bypass Solenoid Valve:
 P/N 17012-S01-A00
 H/C 5999016
 ECM/PCM:
 P/N 37820-P2P-A12
 H/C 6104426

Defect Code: 072
 Contention Code: C01
 Skill Level: Repair Technician

Out of warranty: Any repair performed after warranty expiration may be eligible for goodwill consideration by the District Parts and Service Manager or your Zone Office. You must request consideration, and get a decision, before starting work.

REPAIR PROCEDURE

1. Connect the PGM Tester to the 16P data link connector.
2. Turn the ignition switch to ON (II). Turn on the PGM Tester.
3. From the **PROGRAM MENU** screen, select **HONDA SYSTEMS**.
4. From the **SYSTEM SELECT** screen, select **1: PGM-FI**.
5. From the **TEST MODE MENU** screen, select **6: INSPECTION**.
6. From the **INSPECTION MENU** screen, select **2: EVAP TEST**.
7. From the **EVAP TEST MENU**, select **1: SINGLE SOLENOIDS**.
8. From the **SINGLE SOLENOIDS MENU**, activate the EVAP bypass solenoid valve. Listen for a click and feel for a light tap from the solenoid valve as you activate it.
 - If you can hear the solenoid valve click or feel it tap when activated, disregard this service bulletin, and look for other possible causes.
 - If you cannot hear the solenoid valve click or feel it tap when activated, go to step 9.
9. Replace the EVAP bypass solenoid valve (see section 11 of the appropriate service manual).
10. Test the new solenoid valve with the PGM Tester.
 - If you can hear the solenoid valve click or feel it tap when activated, go to step 15 or 16 as appropriate.
 - If you cannot hear the solenoid valve click or feel it tap when activated, go to step 11.
11. Check the wire harness and the connectors for damage.
 - If you find any damage, repair it, then go to step 12.
 - If you find no damage in the wire harness or connectors, go to step 13.
12. Test the solenoid valve again with the PGM Tester.
 - If you can hear the solenoid valve click or feel it tap when activated, go to step 15 or 16 as appropriate.
 - If you cannot hear the solenoid valve click or feel it tap when activated, go to step 13.
13. Replace the ECM/PCM (see section 11 of the appropriate service manual).
14. Use the PGM Tester to retest the solenoid valve.
 - If you can hear the solenoid valve click or feel it tap when activated, go to step 15 or 16 as appropriate.
 - If you still cannot hear the solenoid valve click or feel it tap when activated, continue with normal troubleshooting.
15. *Insight only:* Disconnect the PGM Tester, and return the vehicle to your customer.
16. *All other affected models:* Use the PGM Tester to run the EVAP system function test (see S/B 02-007, *EVAP System Function Testing and Diagnostics With the PGM Tester*).
 - If the EVAP system passes the function test, disconnect the PGM Tester, and return the vehicle to your customer.
 - If the EVAP system fails the function test, continue with normal troubleshooting.