



1

1. Remove the three washer bolts.

1 FRONT BUMPER

2 WASHER BOLTS (Reuse)

2

2. Position the front bumper on the front under spoiler and install the three washer-bolts removed in step 1.
3. Using a thumbtack, mark the front bumper at each of the two upper holes in the ends of the front under spoiler as shown.
4. Remove the three washer-bolts and installed in step 2, then remove the front under spoiler from the front bumper.

1 WASHER BOLT (Reuse)

2 WASHER BOLTS (Reuse)

3 THUMB TACK

4 FRONT UNDER SPOILER

3

5. Slide a spring nut over each of the four holes in both ends of the front bumper as shown.
6. Slide a clip nut onto the lower edge of the front bumper through each of the four cutouts as shown.

1 CUTOUT

2 SPRING NUTS

3 CUTOUT

4 CLIP NUT

7. Position the front under spoiler on the front bumper and install the washer bolts retained, washer bolts from the kit, and self-tapping screws as shown.

- Before tightening the washer-bolts, check that there is no clearance between the front under spoiler and front bumper.

1 FRONT BUMPER

2 FRONT UNDER SPOILER

3 SELF-TAPPING SCREWS

4 WASHER BOLTS (from the kit)

5 WASHER BOLTS (Reused)

6 SELF-TAPPING SCREWS

7 WASHER BOLT (Reused)

8 WASHER BOLTS (from the kit)