

Thought I'd share the process of swapping an S2000 leather steering wheel for the stock Insight wheel. The leather feels much nicer and the wheel was actually 11 grams lighter!

Tools needed:

- T30 torx bit
- 14mm socket plus extension
- Phillips head screwdriver
- 5mm allen key

- 1) Start by disconnecting the battery, then give it a few minutes to be safe. Don't want to trigger the airbag warning light.
- 2) Next, remove the two plastic clip in panels on the back side of the steering wheel.
- 3) Remove 2x T30 torx screws accessible through the removed plastic pieces.
- 4) Disconnect the airbag connector. It's the yellow plug on the left side of the wheel.
- 5) Gently remove air bag and place aside. Your car should look like this now



- 6) Remove horn wire clip
- 7) Remove 14mm bolt in center of steering wheel
- 🤖 Remove steering wheel. Recommend screwing in the center bolt a few turns then gently pounding outwards from behind the wheel if it is not coming off. Keeping the bolt in will keep the wheel from flying out and damaging the wires.
- 9) With steering wheel removed, unscrew horn assembly by removing the three 5mm bolts.



10) Next, remove the four Phillips screws to allow the plastic backing to come off.



11) Repeat removal for S2000 wheels, and install Insight plastic backing in reverse order of removal.



12) Once wheel assembled with proper plastic backing, return to car and install wheel the same way as removed. Be sure to line up the splines correctly. Torque the center bolt to spec (not sure what spec is, I just went approximately as tight as it felt to remove).

13) Enjoy your new leather wheel!

