

1. Back of seat - pop off panel (by gently pulling on panel with fingertips at corners)



2. Unscrew four screws holding mesh in place



Seat without mesh



Mesh piece and Rick's headrest



Open zipper in back of headrest and slip straps through slits in each corner (photo below).



Install headrest back into seat, pulling straps through the hole. Puncture the strap with something (I used a small screwdriver) where the screws will go. This will bind the straps to the screw hole.



Replace the mesh piece and screw in the screws.



Replace the back panel and the headrests are locked into place. If you need to remove them, reverse the process. Total time to do this was about 10 minutes and to reverse would be 5.