

How Do I Clean My K&N Air Filter

Once you determine your K&N air filter needs to be cleaned, K&N **air filter cleaning kits** simplify the process and restore your air filter to a *like new* condition. Cleaning your K&N air filter is simple when following the 4 easy steps below.

STEP 1 - APPLY K&N AIR FILTER CLEANER

Liberally spray K&N Air Filter Cleaner onto both sides of filter and allow to soak for 10 minutes to loosen the dirt. Do not allow cleaner to dry on air filter.



Clean K&N Panel Air Filter



Clean K&N Round Air Filter



Clean K&N Cone Air Filter

STEP 2 - RINSE YOUR K&N AIR FILTER

Rinse off your air filter with cool low-pressure water applied to the clean side out in order to flush the dirt out of the filter. Continue to rinse the filter until all traces of cleaner are gone. It may be necessary to repeat steps 1 and 2.



Rinse K&N Panel Air Filter



Rinse K&N Round Air Filter



Rinse K&N Cone Air Filter

STEP 3 - DRY YOUR K&N AIR FILTER

After rinsing your filter, gently shake off the excess water and only allow filter to dry naturally. Do not apply oil until the air filter is completely dry.

STEP 4 - APPLY K&N FILTER OIL

When using the **air filter oil squeeze bottle** found in K&N **filter cleaning kit 99-5050**, apply K&N air filter oil evenly along the crown of each pleat. Allow the oil to wick for approximately 20 minutes then touch up any light areas on either side of filter until there is a uniform red color at all areas. K&N offers **1/2 ounce pillow pack air filter oil** for the smaller jobs and **one gallon jug air filter oil** for bigger jobs. Individuals who require a large supply of oil on hand, K&N also offers **5 gallon pails of air filter oil**.



Squeeze Oil K&N Panel Air Filter



Squeeze Oil K&N Round Air Filter



Squeeze Oil K&N Cone Air Filter

When using the **air filter oil aerosol spray** found in K&N **filter cleaning kit 99-5000** or K&N's **12.25 oz aerosol air filter oil**, spray the oil evenly along the crown of each pleat holding nozzle about 3" away. Allow oil to wick for approximately 20 minutes. Touch up any light areas on either side of the filter until there is a uniform red color at all areas.



Aerosol Oil K&N Panel Air Filter



Aerosol Oil K&N Round Air Filter



Aerosol Oil K&N Cone Air Filter

The above process is the only approved procedure for maintaining your K&N Air Filter.