

## **Exterior temp display offset**

---

Only do this if you know your exterior temp is off, it can be offset by  $\pm 5$  degrees.

With the key on hold trip until you see the temp change to 0 - 1-5 and then -1-5. If your temp reads 76 but the actual temp is 74 then choose -2 by letting go of the trip button at that number.

Note: Your trip will reset while holding the trip button but just keep holding it to get the temp adjustment control, the trip will return back to whatever mileage it was at prior to the temp adjustment control.

---

-Mac-